


General Guidelines


1. Inspect the carton and cooler for evidence of rough handling and concealed damage. Damage should be filed with carrier.
2. Read and follow all directions to prevent damage to the water cooler and to the user.
3. Use only water. Do not use for storing coffee, tea or other beverages.
4. Be sure the electric supply matches to the water cooler. Check out the water cooler's voltage by the specifications on the water cooler.



NOTE: The appliance must be positioned so that the plug is accessible.


5. Regular cleaning & sanitizing is advised to ensure satisfactory water quality and will help to keep the water cooler running efficiently and economically.

See "Cleaning Instructions" section.



6. Periodically remove dirt and lint from the condenser on the back of the water cooler.

7. Place the water cooler within reach of a suitable grounded electrical outlet.




8. Water from hot faucet will be extremely hot and may scald.

NOTE: Child proof faucets can be made available.

The water cooler is difficult for children to use, but easy for adults to. (Contact your agent)

9. Do not use the water faucets as handles to carry the water cooler.

NOTE: This part of the water cooler may break and cause leaks if pulled by force.



10. The recommended placement of the water cooler is indoors.

Keep away from direct sunlight and excessive moisture.

